## Technical Bulletin

## **TCK7 Installation tips**

## Identifying the correct timing marks

Engine Codes: 1.6 HDi 16V (DV6) used by Citroen, Peugeot, Ford, Mazda & Volvo.

**Issue:** Engines are fitted with one of two types of timing chains depending on the camshaft

gears fitted. Camshaft gears are marked with either an arrow or a square symbol and

this dictates the positioning of the timing chain.

**Solution:** FAI has developed a universal chain incorporating both bright and black links to

remove the guess work. The graphics below represent the two options and the correct

alignment for installation. Visit faiauto.com/ecat for full list of application data.











